


Transfer Key

Product ID: TK

The Transfer Key is used to transfer information between the Acsys Lock and the Acsysware Management Software System. The primary role of the Transfer Key is to initialize/delete locks. The other usage is to download locks' access logs and transfer them to the database. Finally, the Transfer Key is used to blacklist lost keys used on the locks.



GENERAL	
Dimensions	40.7 x 72.7 x 17.8 mm
Material	BLADE SUS 316L / TOP COVER PC+25% GF / LED LENS / SWIVEL SUS 304
ENVIRONMENT	
Temperature	-20 °C to 55 °C (Storage & Operation)
Relative Humidity (RH)	5 to 95% (Without Condensation)
ELECTRONICS	
Battery Type	2 x LR1
Battery Life	1 year
Encryption	AES 128-bit
Visual Indicator	LED: 1 x Tri-color (Green, Red, Orange)
COMPATIBILITY	
Locks	All Acsys lock types
CERTIFICATION	
	CE
WARRANTY	
Warranty	1 year

For more information
To learn more about Acsys International

visit www.acsys.com
Acsys International Ltd.

DISCLAIMER: This document gives certain information about products and/or services provided by Acsys International Limited or its related companies (referred to as "Acsys"). The information is indicative only and is subject to change without notice meaning it may be out of date at any given time. Although every commercially reasonable effort has been taken to ensure the quality and accuracy of the information, Acsys makes no representation as to its accuracy or completeness and it should not be relied on as such.